

Double Hob (Electric)

Please read the user instructions carefully before use

OPERATING INSTRUCTIONS

Connect the unit to the electricity supply. The green neon will light up. Turn the control knob to set the desired temperature.

CLEANING AND MAINTENANCE

CLEANING

Disconnect the unit from the electricity supply and allow to cool before starting to clean. Use a mild detergent in hot water and a soft cloth. Do not use abrasive creams or scourers.