

# HEATED DISPLAY UNIT

**Please read the following carefully before using this appliance**

## OPERATING INSTRUCTIONS

Connect the unit to the electricity supply. Ensure that the cable is in good condition. Switch the unit on and turn the temperature controller to the desired setting. Wait for about 20 minutes for the unit to heat up. Place the dishes/ Gastronorm containers with hot food onto the aluminium hob surface.

Switch on the Infra-red lamp.

## CLEANING AND MAINTENANCE

### CLEANING

Disconnect the product from the electricity supply and ensure that it is cool to touch, before starting to clean. Use a mild detergent in hot water and a soft cloth. Do not use abrasive creams or scourers. Use

a suitable polish on the exterior metal surfaces by spraying onto the cloth (not directly onto the steel).

The Infra-red lamps on LD units are user replaceable. Disconnect the unit from the electricity supply and ensure the unit is cool to touch.

The lamp is a “bayonet” type fit. To remove, push the lamp carefully to one side into the end connector (against light spring resistance) allowing the other end to detach from its connector. Dispose of the old lamp safely. Fitting the new lamp is the reverse of the above sequence.

