

# Electric Grill

## User Instructions

**Please read all information carefully before using this appliance**

### GENERAL USE

Unless otherwise stated in the equipment instructions the following convention applies where indicator lights are fitted to appliances:

Green on - power to unit.

Amber on - power to element.

Amber off - temperature reached.

### GRILL OPERATION

1. The grill can be used free standing.
2. Switch on the power supply. The green neon indicates that power is on.

Adjust the level of heat by means of the control knob

### USER MAINTENANCE

1. Before working on or cleaning the equipment, **isolate it from the power supply** and allow it to cool to a safe working temperature.
2. Clean units regularly with hot water and detergent, do not use abrasive or chlorine based cleaners on stainless steel. Take care to avoid wetting electrical components. **Do not use a water jet.**

